

 COOLANT SYSTEM

COOLANT SYSTEM CLEANER

PT#17022 | RLO#1086088 | UNIT 12 oz. | CASE SIZE 12/cs | PALLET UNITS 1428

Helps remove rust, scale and sludge.



- Helps Remove Rust, Scale, and Sludge
- Prepares Coolant System for new Fluid
- Helps Improve Coolant System Performance and Efficiency
- Protects Water Pumps
- Helps Prevent Damage Due to Corrosion
- Ideal For Exchange Machine Use

Prolongs new coolant life



Manufactured for **Red Line Synthetic Oil**
6100 Egret Court Benicia, CA 94510
707-745-6100

REDLINECHEMICALS.COM





COOLANT SYSTEM

COOLANT SYSTEM CLEANER

PT#17022

RLO#1086088

UNIT 12 oz.

CASE SIZE 12/cs

PALLET UNITS 1428



Quickly removes rust, scale & grease in one easy step.

- Safe for all metal, aluminum, rubber and plastic parts
- Neutralizer not needed
- Compatible with all antifreeze including extended life coolants
- Ideal for flushing exchange use

RECOMMENDED SERVICE PROCEDURE:

- 1 Drain cooling system and refill with fresh water.
- 2 Shake bottle well and pour contents into cold radiator. Replace radiator cap.
- 3 Turn heater control to hot.
- 4 Start engine and idle for 30 minutes.
- 5 Shut off engine and drain radiator after it has cooled.
- 6 Refill with water and drain several times until fluid is clear. NOTE: Disposal of fluid in sewers or on the ground is prohibited in California and several other states. Dispose of fluid in accordance with local laws.
- 7 Refill radiator with antifreeze/coolant and water.

EXCHANGE MACHINE DIRECTIONS:

- 1 To prevent burns, make all adapter and machine connections to a cold radiator/engine.
- 2 Remove radiator cap & add bottle contents. Replace radiator cap.
- 3 Check connections and follow flushing machine directions.



Manufactured for **Red Line Synthetic Oil**
6100 Egret Court Benicia, CA 94510
707-745-6100

REDLINECHEMICALS.COM

